

FIGURE 2-7: Configuring TCP/IP.

- Use the Following IP Address: If your computer must have a specific IP address, choose this option and then type the computer's IP address, subnet mask, and default gateway address. (For more information about these settings, see Chapter 6.)
- Obtain DNS Server Address Automatically: The DHCP server can also provide
 the address of the Domain Name System (DNS) server that the computer
 should use. Choose this option if your network has a DHCP server. (See
 Chapter 6 for more information about DNS.)
- Use the Following DNS Server Addresses: Choose this option if a DNS server isn't available. Then type the IP addresses of the primary and secondary DNS servers.

Joining a Windows Computer to a Domain

When Windows first installs, it isn't joined to a domain network. Instead, it's available as part of a workgroup, which is an unmanaged network suitable only for the smallest of networks with just a few computers and without dedicated servers. To use a computer in a domain network, you must join the computer to the domain. Here are the steps for Windows 10:

 Click the Start icon (or press the Start button on the keyboard), and then tap or click Settings.

The Settings page appears (refer to Figure 2-1).